



# KISCO MANUFACTURING

C O R P O R A T I O N

5155 ARGYLE ST, PORT ALBERNI, BC CANADA V9Y 1V3

PHONE: (604) 823-7456

Replacing a Thermostatic Cartridge models B-E

DISCONNECT UNIT POWER AND TURN OFF WATER BEFORE BEGINNING

Remove Strainers to let water pressure out

- 1- Remove plug from knob using a small screw driver
- 2- Undo screw in center of knob using allen key
- 3- Gently wiggle knob until it comes off
- 4- Remove 6 plugs from front plate
- 5- Using a Phillips screwdriver undo all 6 screws
- 6- Now lift front cover slowly. There are two green plugs attaching the front plate to the main body. Pull firmly on the green plug..DO NOT pull on wires
- 7- Turn Black knob counterclock wise until it comes off.
- 8- Using a screwdriver pry off the plastic ring
- 9- Now using a wrench remove the Thermostatic Cartridge
- 10- Replace with new cartridge
- 11- Attach plastic ring by firmly pressing down, it will snap in place
- 12- Reattach black knob
- 13- Re-attach front cover by plugging in green plugs firmly
- 14- Place front cover back on
- 15- Fasten screws
- 16- Replace caps to water strainers
- 17- Turn water on
- 18- Plug in unit
- 19- Place knob on black hub.
- 20- While running water through unit turn knob until the screen shows a water temperature between 30 and 35 degrees Celcius and is constant.
- 21- Stop running water
- 22- Remove knob and reposition so that the correct number is at the indicator arrow that corresponds with the digital read out.
- 23- Tighten center screw
- 24- Replace all plastic plugs
- 25- TEST

